

SITE PREPARATION

For a faster, more effective installation

Before your Screed It installation team arrives on site, there are a number of preparations you can make to ensure the day goes to plan. The more prepared you are for your underfloor heating, insulation and screed installation, the faster and more effective the work will be.

Here's how you can prepare your site for installation:

Access and parking

We will need access to the site and parking for a large van with a trailer (our pump), and a concrete mixing truck. We appreciate this isn't always easy and you may need to speak to your neighbours to allow room. We can pump from up to 150 meters away, but the closer we are, the safer your site and our workers are.

Waste disposal

We will need somewhere to dispose of waste, such as pipe and insulation cut offs and surplus screed. Ideally a builder's skip with plenty of room available will be onsite prior to our arrival.

Water supply

We will need a water supply on site suitable for a hose connection, so that we can prime the pump and clean down our equipment after the installation. We will also fill and test the underfloor heating system once laid.

Clear, clean and tidy

The area we are screeding needs to be completely free from other building materials and tools, making sure all electrical cables are tied up and secured above the finished floor level of the screed. Once clear, sweep the area thoroughly removing any plaster or concrete snots so that the insulation boards will sit flat.

Weather protection

If your building is not yet water tight, any unglazed doors and windows will need to be temporarily sealed. It is important to protect new screed from the weather for 48 hours into the curing process.

If you have any questions or concerns about the preparation of your site prior to our arrival, contact our helpful sales team on 0800 756 1394.



0800 756 1394

Contact us for your FREE Quote

www.screedit.co.uk